
ANTI-SKID BRAKING SYSTEM (ABS) <4WD>

ANTI-SKID BRAKING SYSTEM (ABS) <4WD>

CONTENTS

35209000138

GENERAL INFORMATION	3	TROUBLESHOOTING	5
SERVICE SPECIFICATION	4	FRONT DISC BRAKE	15
LUBRICANTS	4	WHEEL SPEED SENSOR	19
SPECIAL TOOLS	4	G-SENSOR*	20

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

The SRS includes the following components: impact sensor, SRS diagnosis unit, SRS warning lamp, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

For the items below, refer to **GROUP 35A.**

SEALANTS

ON-VEHICLE SERVICE

- Brake Pedal Check and Adjustment
- Stop Lamp Switch Inspection
- Brake Booster Operating Test
- Check Valve Operation Check
- Brake Booster Vacuum Switch Check
- Load Sensing Spring Length Check and Adjustment
- Load Sensing Proportioning Valve Function Test
- Front Disc Brake Rotor Check
- Brake Lining Thickness Check
- Brake Drum Inside Diameter Check
- Brake Lining and Brake Drum Connection Check

BRAKE PEDAL

LOAD SENSING PROPORTIONING VALVE

REAR DRUM BRAKE

For the items below, refer to **GROUP 35B.**

ON-VEHICLE SERVICE

- Bleeding
- Disc Brake Pad Check and Replacement
- Wheel Speed Sensor Output Voltage Check
- Hydraulic Unit Check
- Solenoid Valve Check
- Motor Operation Check
- Motor Relay and Valve Relay Continuity Check
- Remedy for a Flat Battery

MASTER CYLINDER AND BRAKE BOOSTER

HYDRAULIC UNIT

ABS-ECU

GENERAL INFORMATION


35200010130

The ABS consists of wheel speed sensors, stop lamp switch hydraulic unit and the ABS-ECU. If a problem occurs in the system, the malfunctioning system can be identified by means of the diagnosis function, and the trouble symptom memory will not be erased even if the ignition switch is turned to

OFF. (However, it will be erased if the battery is disconnected.)
In addition, reading of diagnosis codes and data list and actuator of testing are possible using the MUT-II.

Items	Specifications
Speed sensor	Magnet coil type
Front rotor teeth	47
Rear rotor teeth	47

CONSTRUCTION DIAGRAM



A14V0087

NOTE

- *1: For R.H. drive vehicles, those parts are installed at the right side.
- *2: Diesel-powered vehicles – L.H. drive vehicles.
- *3: Except diesel-powered vehicles – L.H. drive vehicles.

- | | |
|-----------------------|-----------------------------------|
| 1. ABS valve relay | 8. Diagnosis connector |
| 2. ABS motor relay | 9. Hydraulic unit |
| 3. ABS warning lamp | 10. G-sensor |
| 4. Stop lamp switch | 11. 4WD position detection switch |
| 5. Rotor | 12. Free wheel engage switch |
| 6. Wheel speed sensor | 13. Rear differential lock-ECU |
| 7. ABS-ECU | 14. 4WD indicator-ECU |

SERVICE SPECIFICATION

35200030143

Items		Standard value	Limit
Front disc brake pad thickness mm		10	2.0
G-sensor output voltage V	When installed	2.4 – 2.6	–
	When removed with arrow mark facing down	3.4 – 3.6	–





LUBRICANTS

35200040030

Items	Specified lubricant
Brake fluid	DOT3 or DOT4
Brake piston seal	Repair kit grease
Guide pin boot inner surfaces	
Lock pin boot inner surfaces	
Piston boot mounting grooves	
Brake piston boot inner surfaces	
Lock pin bush inner surfaces	
Piston cup surface	

SPECIAL TOOLS

35200060142

Tool	Number	Name	Use
 B991502	MB991502	MUT-II sub assembly	For checking of ABS (Diagnosis code display when using the MUT-II)
 B991529	MB991529	ABS check harness	For checking of ABS (Diagnosis code display when using the ABS warning lamp)
 B991348	MB991348	Test harness set	For checking of G-sensor
 B990964	MB990964 MB990520	Brake tool set	Pushing-in of the brake piston

TROUBLESHOOTING

35101110143

STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

NOTES WITH REGARD TO DIAGNOSIS

The phenomena listed in the following table are not abnormal.

Phenomenon	Explanation of phenomenon
System check sound	When starting the engine, a thudding sound can sometimes be heard coming from inside the engine compartment, but this is because the system operation check is being performed, and is not an abnormality.
ABS operation sound	<ol style="list-style-type: none"> 1. Sound of the motor inside the ABS hydraulic unit operation. (whine) 2. Sound is the generated along with vibration of the brake pedal. (scraping) 3. When ABS operates, sound is generated from the vehicle chassis due to repeated brake application and release. (Thump: suspension; squeak: tyres)
ABS operation (Long braking distance)	For road surfaces such as snow-covered roads and gravel roads, the braking distance for vehicles with ABS can sometimes be longer than that for other vehicles. Accordingly, advise the customer to drive safely on such roads by lowering the vehicle speed and not being too overconfident.
Shock during system operation check	Shock may be felt when the brake pedal is depressed slightly at a low driving speed. This occurs due to ABS operation check (check at a vehicle speed of 8 km/h after starting), and does not indicate any malfunction.

Diagnosis detection condition can vary depending on the diagnosis code.

Make sure that checking requirements listed in the “Comment” are satisfied when checking the trouble symptom again.

DIAGNOSIS FUNCTION

35201120108

DIAGNOSIS CODES CHECK

Read a diagnosis code by the MUT-II or ABS warning lamp.
(Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.)

ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

INSPECTION CHART FOR DIAGNOSIS CODES

35201130163


Inspect according to the inspection chart that is appropriate for the malfunction code.

Diagnosis code No.	Inspection item	Diagnosis content	Reference page
11	Front right wheel speed sensor	Open or short circuit	Refer to GROUP 35B – Troubleshooting.
12	Front left wheel speed sensor		
13	Rear right wheel speed sensor		
14	Rear left wheel speed sensor		
15	Wheel speed sensor	Abnormal output signal	Refer to GROUP 35B – Troubleshooting.
16	Power supply system		Refer to GROUP 35B – Troubleshooting.
21	Front right wheel speed sensor	Abnormal	Refer to GROUP 35B – Troubleshooting.
22	Front left wheel speed sensor		
23	Rear right wheel speed sensor		
24	Rear left wheel speed sensor		
25	Free wheel engage switch		35C-7
26	4WD position detection switch		35C-8
27	Rear differential lock detection switch		35C-9
32	G-sensor system		35C-10
33	Stop lamp switch system		Refer to GROUP 35B – Troubleshooting.
41	Front right solenoid valve		Refer to GROUP 35B – Troubleshooting.
42	Front left solenoid valve		
43	Rear solenoid valve		
51	Valve relay		Refer to GROUP 35B – Troubleshooting.
53	Motor relay, motor		Refer to GROUP 35B – Troubleshooting.
63	ABS-ECU		Refer to GROUP 35B – ABS-ECU. (Replace the ABS-ECU.)
64			


INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODES

For diagnosis code numbers other than those listed below, refer to GROUP 35B – Troubleshooting.

Code No. 25 Free wheel engage switch	Probable cause
ABS-ECU determines that an open circuit exists in the free wheel engage switch system.	<ul style="list-style-type: none"> ● Malfunction of wiring harness or connector ● Malfunction of 4WD indicator-ECU ● Malfunction of ABS-ECU



Code No. 26 4WD position detection switch	Probable cause
<p>This code is output at the following times: ABS-ECU determines that an open circuit exists in the 4WD detection switch system. The free wheel engage switch is off and the 4WD detection switch is on at a vehicle speed of 15km/h or more for 5 seconds or more.</p>	<ul style="list-style-type: none"> • Malfunction of wiring harness or connector • Malfunction of free wheel engage switch • Malfunction of 4WD indicator-ECU • Malfunction of 4WD position detection switch • Malfunction of ABS-ECU




Trouble symptom	Main cause	Remedy
Even when the transfer shift lever is in the "4H" position, the 4WD front wheel indicator lamp does not illuminate.	Broken harness wire between the 4WD indicator-ECU and the free-wheel engage switch, or broken earth wire from the free wheel engage switch	Repair the harness.
	Free wheel engage switch is defective.	Replace the switch.
Even when the transfer shift lever is in the "4H" position, the free wheel differential indicator lamp does not illuminate.	Broken harness wire between the 4WD indicator-ECU and the 4WD position detection switch	Repair the harness.
	Broken wire in the 4WD indicator-ECU circuit	4WD indicator-ECU inspection (Refer to GROUP 22 – 4WD indicator-ECU.)
Free wheel differential indicator lamp illuminates regardless of the position of the transfer shift lever.	Short in the harness wire in the 4WD position detection switch circuit	Repair the harness.
	4WD position detection switch is defective.	Replace the switch.
	Short in the ABS-ECU circuit	Replace the ABS-ECU.
	Short in the 4WD indicator-ECU circuit	4WD indicator-ECU inspection (Refer to GROUP 22 – 4WD indicator-ECU.)
No indicator is illuminated	Power circuit in the 4WD indicator-ECU is defective.	Repair the harness.
	4WD indicator-ECU is defective.	4WD indicator-ECU inspection (Refer to GROUP 22 – 4WD indicator-ECU.)


NOTE

When checking a short in the ABS-ECU circuit, remove the ABS-ECU connector and check if the 4WD indicator returns to normal. If it returns to normal, the ABS-ECU is defective. Furthermore, if the ABS-ECU is normal, then the 4WD indicator-ECU will be defective.


Code No. 27 Rear differential lock detection switch <Vehicles with rear differential lock>	Probable cause
The ABS-ECU determines that an open circuit occurs in rear differential detection switch system.	<ul style="list-style-type: none"> • Malfunction of wiring harness or connector • Malfunction of rear differential lock-ECU • Malfunction of ABS-ECU



Code No. 27 Rear differential lock detection switch <Vehicles without rear differential lock>	Probable cause
For vehicles without rear differential lock, battery positive voltage is applied to the ABS-ECU terminal No. 46. This code is output when this line is interrupted.	<ul style="list-style-type: none"> • Malfunction of wiring harness or connector • Malfunction of ABS-ECU



Code No. 32 G-sensor system	Probable cause
This code is output at the following times: The G-sensor output is less than 0.5 V or more than 4.5 V. An open or short circuit is present in the G-sensor system.	<ul style="list-style-type: none"> ● Malfunction of G-sensor ● Malfunction of wiring harness or connector ● Malfunction of ABS-ECU



ABS WARNING LAMP INSPECTION

35201200086

Refer to GROUP 35B – Troubleshooting.

INSPECTION CHART FOR TROUBLE SYMPTOMS

35201140159

Refer to GROUP 35B – Troubleshooting.

DATA LIST REFERENCE TABLE

35201150107

The following items can be read by the MUT-II from the ABS-ECU input data.

1. When the system is normal

Item No.	Check item	Checking requirements	Normal value
11	Front-right wheel speed sensor	Perform a test run	Vehicle speeds displayed on the speedometer and MUT-II are identical.
12	Front-left wheel speed sensor		
13	Rear-right wheel speed sensor		
14	Rear-left wheel speed sensor		
16	ABS-ECU power supply voltage	Ignition switch power supply voltage and valve monitor voltage	9 – 16 V
25	Free wheel engage switch	Engage 4WD	ON
		Engage 2WD	OFF
26	4WD detection switch	Place the transfer lever at 4H.	ON
		Place the transfer lever at 2H.	OFF
27	Rear differential lock detection switch	Turn on the switch.	ON
		Turn off the switch.	OFF
32	G-sensor output voltage	Stop the vehicle.	2.4 – 2.6 V
		Perform a test run.	Display value fluctuates with a mean value of 2.5 V.
33	Stop lamp switch	Depress the brake pedal.	ON
		Release the brake pedal.	OFF

2. When the ABS-ECU shut off ABS operation.

When the diagnosis system stops the ABS-ECU, the MUT-II display data will be unreliable.

ACTUATOR TEST INSPECTION TABLE

35201160056

Refer to GROUP 35B – Troubleshooting.

CHECK AT ABS-ECU



TERMINAL VOLTAGE CHECK CHART

1. Measure the voltages between terminals (15), (16), (25) and (42) (earth terminals) and each respective terminal.

NOTE

Do not measure terminal voltage for approx. 3 seconds after the ignition switch is turned on. The ABS-ECU performs the initial check for that period.

2. The terminal layouts are shown in the illustrations below.



14W0043

Connector terminal No.	Signal	Checking requirements		Normal condition
1	Output to front-left hydraulic unit solenoid valve (OUT side)	Ignition switch: ON (When solenoid valve is off approximately 1 second after engine is started)		System voltage
2	Output to rear hydraulic unit solenoid valve (OUT side)			
3	Output to rear hydraulic unit solenoid valve (IN side)			
4	G-sensor signal	Ignition switch: ON		2.4 – 2.6 V (Horizontal condition)
13	ABS-ECU power supply	Ignition switch: ON		System voltage
		Ignition switch: START		0 V
14	Output to front-left hydraulic unit solenoid valve (IN side)	Ignition switch: ON (When solenoid valve is off approximately 1 second after engine is started)		System voltage
17	G-sensor earth	Always		0 V
26	Output to relay power supply	Ignition switch: ON		System voltage
31	Free wheel engage switch	Ignition switch: ON	2WD	System voltage
			4WD	1 V or less
32	Memory power supply	Always		System voltage
34	Input from stop lamp switch	Ignition switch: ON	Stop lamp switch ON	System voltage
			Stop lamp switch OFF	1 V or less
35	Input from 4WD detection switch	Ignition switch: ON	Transfer lever position: 2H	System voltage
			Transfer lever position: 4H	1 V or less
36	MUT-II	Connect the MUT-II.		Serial communication with MUT-II
		Do not connect the MUT-II.		1 V or less

Connector terminal No.	Signal	Checking requirements		Normal condition
37	Output to valve relay	Ignition switch: ON	Approximately 1 second after engine is started. The relay is on.	2 V or less
			The system runs down. The relay is off.	System voltage
38	Output to motor relay	Ignition switch: ON (Approximately 1 second after engine is started)	Motor is on	2 V or less
			Motor is off	System voltage
39	Idle-up solenoid valve (+)	Ignition switch: ON (When motor is on approximately 1 second after engine is started)		System voltage
41	Output to front-right hydraulic unit solenoid valve (OUT side)	Ignition switch: ON (When solenoid valve is off approximately 1 second after engine is started)		System voltage
43	Idle-up solenoid valve (-)	Ignition switch: ON (When motor is on approximately 1 second after engine is started)		2 V or less
45	Input from free wheel engage switch	Ignition switch: ON	Engage 2WD	System voltage
			Engage 4WD	1 V or less
46*1	Ignition switch	Ignition switch: ON		System voltage
		Ignition switch: START		0 V
46*2	Input from rear differential lock detection switch	Ignition switch: ON	Rear differential lock switch: ON	0 V
			Rear differential lock switch: OFF	System voltage
47	Input from diagnosis indication selection	Connect the MUT-II.		0 V
		Do not connect the MUT-II.		Approx. 12 V
48	Input from valve relay monitor	Ignition switch: ON		System voltage
49	Motor monitor	Ignition switch: ON (Approximately 1 second after engine is started)	Motor is on	System voltage
			Motor is off	0.5 V or less
50	Output to ABS warning lamp	Ignition switch: ON	The lamp is switched off	System voltage
			The lamp illuminates	0 – 2 V
52	Output to front-right hydraulic unit solenoid valve (IN side)	Ignition switch: ON (When solenoid valve is off approximately 1 second after engine is started)		System voltage



NOTE

*1: Vehicles without rear differential lock

*2: Vehicles with rear differential lock

RESISTANCE AND CONTINUITY BETWEEN HARNESS-SIDE CONNECTOR TERMINALS

1. Turn the ignition switch off and disconnect the ABS-ECU connectors before checking resistance and continuity.
2. Check them between the terminals indicated in the table below.
3. The terminal layouts are shown in the illustrations below.



14W0042


Connector terminal No.	Signal	Normal condition
1 – Body earth	Front-left solenoid valve (OUT side)	2.2 Ω
2 – Body earth	Rear solenoid valve (OUT side)	2.2 Ω
3 – Body earth	Rear solenoid valve (IN side)	5.0 Ω
7 – 20	Front-left wheel speed sensor (+ wire)	1.2 – 1.4 kΩ
8 – 21	Rear-right wheel speed sensor (+ wire)	1.2 – 1.4 kΩ
9 – 22	Rear-left wheel speed sensor (+ wire)	1.2 – 1.4 kΩ
10 – 23	Front-right wheel speed sensor (+ wire)	1.2 – 1.4 kΩ
14 – Body earth	Front-left solenoid valve (IN side)	5.0 Ω
15 – Body earth	ABS-ECU earth	Continuity
16 – Body earth		
25 – Body earth		
39 – 43	Idle-up solenoid valve	37 – 44 Ω
41 – Body earth	Front-right solenoid valve (OUT side)	2.2 Ω
42 – Body earth	ABS-ECU earth	Continuity
48 – Body earth	Input from valve relay monitor	Continuity
49 – Body earth	Motor monitor	Continuity
52 – Body earth	Front-right solenoid valve (IN side)	5.0 Ω

FRONT DISC BRAKE**REMOVAL AND INSTALLATION****Pre-removal Operation**

- Brake Fluid Draining

Post-installation Operation

- Brake Fluid Supplying
- Brake Line Bleeding
(Refer to GROUP 35B – On-vehicle Service.)






A14V0047

Removal steps


1. Brake tube
2. Front brake assembly (Refer to GROUP 35B – Front Disc Brake.)
3. Brake hose bracket
4. Brake disc (Refer to GROUP 26 – Front Hub Assembly.)

DISASSEMBLY AND REASSEMBLY


35200620029



Brake caliper kit



Pad kit



Seal and boot kit

00004876

Caliper assembly disassembly steps




1. Lock pin
2. Guide pin
3. Bushing
4. Caliper support (Pad, clip and shim)
5. Pin boot
6. Boot ring
7. Piston boot
8. Piston
9. Piston seal
10. Caliper body



Pad assembly disassembly steps



1. Lock pin
2. Guide pin
3. Bushing
4. Caliper support (Pad, clip and shim)
11. Pad and wear indicator assembly
12. Pad assembly
13. Outer shim
14. Clip



DISASSEMBLY SERVICE POINTS

When disassembling the disc brakes, disassemble both sides (left and right) as a set.


◀A▶ PISTON BOOT/PISTON REMOVAL

Pump in compressed air through the brake hose installation hole and remove the pistons and piston boot.

Caution

When removing the pistons, be sure to use the handle of a plastic hammer and adjust the height of the two pistons while pumping air slowly in so that the pistons protrude evenly.

Do not remove one piston completely before trying to remove the other piston because it will become impossible to remove the second piston.



◀B▶ PISTON SEAL REMOVAL


(1) Remove piston seal with finger tip.

Caution

Do not use a screwdriver or other tool to prevent damage to inner cylinder.

(2) Clean piston surface and inner cylinder with trichloro-ethylene, alcohol or specified brake fluid.

Specified brake fluid: DOT3 or DOT 4



REASSEMBLY SERVICE POINT


▶A◀ LOCK PIN/GUIDE PIN INSTALLATION

Install the lock pin and the guide pin to the caliper body as illustrated.

INSPECTION

35200630015

- Check cylinder for wear, damage or rust.
- Check piston surface for wear, damage or rust.
- Check caliper body or sleeve for wear.
- Check pad for damage or adhesion of grease, check backing metal for damage.

**PAD WEAR CHECK**

Measure thickness at the thinnest and worn area of the pad. Replace pad assembly if pad thickness is less than the limit value.

Standard value: 10 mm

Limit: 2.0 mm

Caution


1. When the limit is exceeded, replace the pads at both sides, and also the brake pads for the wheels on the opposite side at the same time.
2. If there is a significant difference in the thicknesses of the pads on the left and right sides, check the sliding condition of the piston, lock pin and guide pin.

WHEEL SPEED SENSOR

35200830170

REMOVAL AND INSTALLATION**Post-installation Operation**

- Wheel Speed Sensor Output Voltage Checking
(Refer to GROUP 35B – On-vehicle Service.)



A14V0056

1. Front speed sensor
2. Front rotor
(Refer to GROUP 26 – Front Hub.)

NOTE

The rear wheel speed sensor is the same as 2WD.

INSPECTION

Refer to GROUP 35B.

35200840135

G-SENSOR

35201010078


REMOVAL AND INSTALLATION

CAUTION: SRS

When removing and installing the G-sensor from/to vehicles equipped with SRS, do not let it bump against the SRS diagnostic unit or other components.

Pre-removal and Post-installation Operation

- SRS diagnostic unit Removal and Installation (Refer to GROUP 52B.)



A 14V0065

Removal steps

1. G-sensor assembly
2. G-sensor bracket
3. G-sensor

Caution

Do not drop the G-sensor or subject it to shocks.

INSPECTION

35201020057



- (1) Disconnect the G-sensor connector and connect the special tool between the terminals of the disconnected connector.
- (2) Turn the ignition switch to ON and take a reading of the following output voltage. Between terminals (2) and (3).

Standard value: 2.4 – 2.6 V

- (3) With the special tool still connected, secure the G-sensor so that the arrow mark on the sensor mounting surface faces straight down, and then take a reading of the following output voltage between terminals (2) and (3).

Standard value: 3.4 – 3.6 V

- (4) If the voltages is outside the standard value, after checking to be sure that there is no abnormality in the power supply and earth wires, replace the G-sensor.



ANTI-SKID BRAKING SYSTEM (ABS) <4WD>



CONTENTS

GENERAL 2

Outline of Change 2

TROUBLESHOOTING 3

ON-VEHICLE SERVICE

Wheel Speed Sensor Output Voltage Check
..... Refer to GROUP 35B

Hydraulic Unit Check

..... Refer to GROUP 35B

ABS Warning Lamp Relay Continuity Check

..... Refer to GROUP 35B

ABS-ECU AND HYDRAULIC UNIT


..... Refer to GROUP 35B

GENERAL

OUTLINE OF CHANGE

- The ABS system has been revised as follows:
 - (1) The ABS control unit (ABS-ECU) and the hydraulic unit have been unified.
 - (2) The motor relay and the valve relay have been discontinued.
 - (3) The ABS warning lamp relay has been added.

CONSTRUCTION DIAGRAM



- | | |
|--|---|
| 1. ABS warning lamp relay | 7. 4WD position detection switch |
| 2. Hydraulic unit assembly (integrated in ABS-ECU) | 8. ABS warning lamp |
| 3. Diagnosis connector | 9. G-sensor |
| 4. Stop lamp switch | 10. Freewheel engage switch |
| 5. ABS rotor | 11. Rear differential lock detection switch <Vehicles with rear differential lock system> |
| 6. Wheel speed sensor | |

NOTE

For R.H. drive vehicles, *1 indicates installation at the right aide.

*2: LHD diesel-powered vehicles

*3: Except LHD diesel-powered vehicles

TROUBLESHOOTING

STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Refer to Basic Manual GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

NOTES WITH REGARD TO DIAGNOSIS

The phenomena listed in the following table are not abnormal.

Phenomenon	Explanation of phenomenon
System check sound	When starting the engine, a thudding sound can sometimes be heard coming from inside the engine compartment, but this is because the system operation check is being performed, and is not an abnormality.
ABS operation sound	<ol style="list-style-type: none"> 1. Sound of the motor inside the ABS hydraulic unit operation. (whine) 2. Sound is the generated along with vibration of the brake pedal. (scraping) 3. When ABS operates, sound is generated from the vehicle chassis due to repeated brake application and release. (Thump: suspension; squeak: tyres)
ABS operation (Long braking distance)	For road surfaces such as snow-covered roads and gravel roads, the braking distance for vehicles with ABS can sometimes be longer than that for other vehicles. Accordingly, advise the customer to drive safely on such roads by lowering the vehicle speed and not being too overconfident.
Shock during system operation check	Shock may be felt when the brake pedal is depressed slightly at a low driving speed. This occurs due to ABS operation check (check at a vehicle speed of 8 km/h after starting), and does not indicate any malfunction.

Diagnosis detection condition can vary depending on the diagnosis code.

Make sure that checking requirements listed in the “Comment” are satisfied when checking the trouble symptom again.

DIAGNOSIS FUNCTION

DIAGNOSIS CODES CHECK

Refer to GROUP 35B – Troubleshooting.

ERASING DIAGNOSIS CODES

Refer to GROUP 35B – Troubleshooting.

INSPECTION CHART FOR DIAGNOSIS CODES

Inspect according to the inspection chart that is appropriate for the malfunction code.


Diagnosis code No.	Inspection item	Diagnosis content	Reference page
11	Front right wheel speed sensor	Open or short circuit	Refer to GROUP 35B – Troubleshooting.
12	Front left wheel speed sensor		
13	Rear right wheel speed sensor		
14	Rear left wheel speed sensor		
15	Wheel speed sensor	Abnormal output signal	Refer to GROUP 35B – Troubleshooting.
16	Power supply system		Refer to GROUP 35B – Troubleshooting.
21	Front right wheel speed sensor	Abnormal	Refer to GROUP 35B – Troubleshooting.
22	Front left wheel speed sensor		
23	Rear right wheel speed sensor		
24	Rear left wheel speed sensor		
25	Free wheel engage switch		35C-5
26	4WD position detection switch		35C-7
27	Rear differential lock detection switch		35C-7
32	G-sensor system		35C-8
33	Stop lamp switch system		Refer to GROUP 35B – Troubleshooting.
41	Front right solenoid valve		Refer to GROUP 35B – Troubleshooting.
42	Front left solenoid valve		
43	Rear solenoid valve		
51	Valve driver		Refer to GROUP 35B – Troubleshooting.
53	Motor driver		Refer to GROUP 35B – Troubleshooting.
63	ABS-ECU		Refer to GROUP 35B – ABS-ECU. (Replace the ABS-ECU and hydraulic unit assembly.)

INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODES


For diagnosis code numbers other than those listed below, refer to GROUP 35B – Troubleshooting.

Code No. 25 Free wheel engage switch	Probable cause
<p>This diagnosis code is displayed under the following cases. For case (2), code No. 26 is also displayed at the same time.</p> <p>(1) The ABS-ECU determines that an open circuit exists in the freewheel engage switch system.</p> <p>(2) While the vehicle speed is 20 km/h or more, the freewheel engage switch remains off, and the 4WD position detection switch remains on for five minutes or more until the vehicle speed reaches 0 km/h (The switch signals are combined abnormality).</p>	<ul style="list-style-type: none"> ● Malfunction of wiring harness or connector ● Malfunction of freewheel engage switch ● Malfunction of 4WD position detection switch ● Malfunction of 4WD indicator-ECU ● Malfunction of ABS-ECU and hydraulic unit

<When only code No. 25 is displayed>



<When code Nos. 25 and 26 are displayed simultaneously>




Trouble symptom	Main cause	Remedy
When the transfer shift lever is at "4H" position, the 4WD indicator lamp flashes, but does not remain on.	Broken harness wire between the 4WD indicator-ECU and the free-wheel engage switch, or broken earth wire from the free wheel engage switch	Repair the harness.
	Free wheel engage switch is defective.	Replace the switch.
	4WD indicator-ECU is defective.	Replace the 4WD indicator-ECU
When the transfer shift lever is at "2H" position, the 4WD indicator lamp flashes.	Short in the harness wire in the 4WD position detection switch circuit	Repair the harness.
	4WD position detection switch is defective.	Replace the switch.
	Short in the ABS-ECU circuit	Replace the ABS-ECU.
	4WD indicator-ECU is defective.	Replace the 4WD indicator-ECU.
No indicator is illuminated	Power circuit in the 4WD indicator-ECU is defective.	Repair the harness.
	Broken harness wire between the 4WD indicator-ECU and the freewheel engage switch, or broken earth wire from the freewheel engage switch	Replace the harness.
	Broken harness wire between the 4WD indicator-ECU and the 4WD position detection switch	Repair the harness.
	Freewheel engage switch or 4WD position detection switch is defective.	Repair the switch.
	4WD indicator-ECU is defective.	Replace the 4WD indicator-ECU.

NOTE

When checking a short in the ABS-ECU circuit, remove the ABS-ECU connector and check if the 4WD indicator returns to normal. If it returns to normal, the ABS-ECU is defective. Furthermore, if the ABS-ECU is normal, then the 4WD indicator-ECU will be defective.

Code No. 26 4WD position detection switch system	Probable cause
This diagnosis code is displayed under the following case. For case (2), code No. 25 is also displayed at the same time. (1) The ABS-ECU determines that an open circuit exists in the 4WD position detection switch system. (2) While the vehicle speed is 20 km/h or more, the freewheel engage switch remains off, and the 4WD position detection switch remains on for five minutes or more until the vehicle speed reaches 0 km/h (The switch signals are combined abnormally).	<ul style="list-style-type: none"> ● Malfunction of wiring harness or connector ● Malfunction of freewheel engage switch ● Malfunction of 4WD position detection switch ● Malfunction of 4WD indicator-ECU ● Malfunction of ABS-ECU and hydraulic unit


<When only code No. 26 is displayed>




<When code Nos. 25 and 26 are displayed>

Refer to P.35C-6.


Code No. 27 Rear differential lock detection switch <Vehicles without rear differential lock>	Probable cause
For vehicles without rear differential lock, battery positive voltage is applied to the ABS-ECU terminal No. 46. This code is output when this line is interrupted.	<ul style="list-style-type: none"> ● Malfunction of wiring harness or connector ● Malfunction of ABS-ECU and hydraulic unit assembly



Code No. 27 Rear differential lock detection switch <Vehicles with rear differential lock>	Probable cause
The ABS-ECU determines that an open circuit occurs in rear differential detection switch system.	<ul style="list-style-type: none"> ● Malfunction of wiring harness or connector ● Malfunction of rear differential lock-ECU ● Malfunction of ABS-ECU and hydraulic unit assembly



Code No. 32 G-sensor system	Probable cause
This code is output at the following times: The G-sensor output is less than 0.5 V or more than 4.5 V. An open or short circuit is present in the G-sensor system.	<ul style="list-style-type: none"> ● Malfunction of G-sensor ● Malfunction of wiring harness or connector ● Malfunction of ABS-ECU and hydraulic unit assembly



ABS WARNING LAMP INSPECTION

Refer to GROUP 35B – Troubleshooting.

INSPECTION CHART FOR TROUBLE SYMPTOMS

Refer to GROUP 35B – Troubleshooting.

DATA LIST REFERENCE TABLE

The following items can be read by the MUT-II from the ABS-ECU input data.

1. When the system is normal

Item No.	Check item	Checking requirements		Normal value
11	Front-right wheel speed sensor	Perform a test run		Vehicle speeds displayed on the speedometer and MUT-II are identical.
12	Front-left wheel speed sensor			
13	Rear-right wheel speed sensor			
14	Rear-left wheel speed sensor			
16	ABS-ECU power supply voltage	Ignition switch power supply voltage and valve monitor voltage		9 – 16 V
25	Free wheel engage switch	Engage 4WD		ON
		Engage 2WD		OFF
26	4WD detection switch	Place the transfer lever at 4H.		ON
		Place the transfer lever at 2H.		OFF
27	Rear differential lock detection switch	Vehicles with rear differential	Turn on the switch	ON
			Turn off the switch	OFF
		Vehicles without rear differential lock	Always	OFF
32	G-sensor output voltage	Stop the vehicle.		2.4 – 2.6 V
		Perform a test run.		Display value fluctuates with a mean value of 2.5 V.
33	Stop lamp switch	Depress the brake pedal.		ON
		Release the brake pedal.		OFF

2. When the ABS-ECU shut off ABS operation.

When the diagnosis system stops the ABS-ECU, the MUT-II display data will be unreliable.

ACTUATOR TEST INSPECTION TABLE

Refer to GROUP 35B – Troubleshooting.

CHECK AT ABS-ECU


TERMINAL VOLTAGE CHECK CHART

1. Measure the voltages between terminals (32) and (34) (earth terminals) and each respective terminal.

NOTE

Do not measure terminal voltage for approximately three seconds after the ignition switch is turned on. The ABS-ECU performs the initial check during that period.

2. The terminal layouts are shown in the illustrations below.



Connector terminal No.	Signal	Checking requirement		Normal condition
5*1	Ignition switch	Ignition switch: ON		System voltage
5*2	Input from rear differential lock detection switch	Ignition switch: ON	Rear differential lock switch: ON	0 V
			Rear differential lock switch: OFF	System voltage
7	G-sensor signal	<ul style="list-style-type: none"> ● Ignition switch: ON ● Vehicle: parked on level ground 		2.4 - 2.6 V
9	ABS-ECU power supply	Ignition switch: ON		System voltage
		Ignition switch: START		0 V
11	Input from 4WD detection switch	Ignition switch: ON	Transfer lever position: 2H	System voltage
			Transfer lever position: 4H	1 V or less
12	Input from freewheel engage switch	Ignition switch: ON	Transfer lever position: 2H	System voltage
			Transfer lever position: 4H	1 V or less

NOTE



*1: Vehicles without rear differential lock

*2: Vehicles with rear differential lock

Connector terminal No.	Signal	Checking requirement		Normal condition
13	Input from stop lamp switch	Ignition switch: ON	Stop lamp switch: ON	System voltage
			Stop lamp switch: OFF	1 V or less
14	G-sensor	Always		0V
16	Control output to ABS warning lamp relay.	Ignition switch: ON	The lamp is switch off.	2 V or less
			The lamp is illuminated.	System voltage
23	MUT-II	Connect the MUT-II		Serial communication with MUT-II
		Do not connect the MUT-II		1 V or less
24	Input from diagnosis indication selection	Connect the MUT-II		0 V
		Do not connect the MUT-II		Approximately 12 V
31	Solenoid valve power supply	Always		System voltage
33	Motor power supply			

RESISTANCE AND CONTINUITY BETWEEN HARNESS-SIDE CONNECTOR TERMINALS

1. Turn the ignition switch off and disconnect the ABS-ECU connectors before checking resistance and continuity.
2. Check between the terminals indicated in the table below.
3. The terminal layouts are shown in the illustration below.



14V0128

Connector terminal No.	Signal	Normal condition
20 – 21	Front-left wheel speed sensor	1.2 – 1.4 kΩ
1 – 2	Rear-right wheel speed sensor	1.2 – 1.4 kΩ
18 – 19	Front-right wheel speed sensor	1.2 – 1.4 kΩ
3 – 4	Rear-left wheel speed sensor	1.2 – 1.4 kΩ
32 – body earth	Solenoid valve earth	Continuity
34 – body earth	Motor earth	Continuity