


Fast-moving Parts suitable for Land Rover:

DISCOVERY

Series 2 (from 1999)



CHASSIS / VIN NUMBERS		
SALL ...	XA ...	= 1999
SALL ...	YA ...	= 2000
SALL ...	1A ...	= 2001
SALL ...	2A ...	= 2002
SALL ...	3A ...	= 2003
SALL ...	4A ...	= 2004

All manufacturers parts numbers are used for reference purposes only.

Bearmach Plc accepts no responsibility for the incorrect supply of parts as a result of the information in this catalogue


CONTENTS

Section	Components	Page
Axle	Hubs • Driveshafts • Differential Propshafts	39 ~ 40
Body	Locks • Mirrors • Mudflaps • Panels • Doors Handles • Windows • Finishers	41 ~ 46
Brakes	Discs • Calipers • Pads • Shoes Cylinders • Servos • Cables	47 ~ 48
Clutch	Cover • Plate • Bearings • Cylinder	49
Electrical	Wash/Wipe • Switches • Lighting • Alternators Starter Motors • Ignition Coil • Plugs . . .	50 ~ 52
Exhaust	Manifolds • Silencers • Catalysts Turbocharger • Gaskets	53 ~ 54
Fuel System	Tanks • Pumps • Seals	55
Service Items	Oil Filters • Air Filters • Gaskets Spark Plugs • Glow Plugs	56
Steering	Steering Box • Drag Link • Ball Joint Dampers • Seals	57
Suspension	Front and Rear Components Shock Absorbers • Springs	58 ~ 60


Discovery Series 1 (up to 1999) . . . Page 1

Propshafts

1	TVB000100	PROPSHAFT	TD5	FRONT
1	TVB000220	PROPSHAFT	TD5 AUTO	FRONT
1	TVB000110	PROPSHAFT	V8	FRONT
1	TVB000150	PROPSHAFT	TD5	REAR
1	TVB000140	PROPSHAFT	V8	REAR
2	TVC100010	UNIVERSAL JOINT		
3	TVF100010	COUPLING		REAR
4	TVE100000	GAITER		
5	509045P	BOLT		
6	NZ606041L	NUT		



Hubs & Driveshafts




FRONT

1	TAY100060	HUB ASSEMBLY	
2	TDB000220	DRIVESHAFT	LONG
2	TDB000230	DRIVESHAFT	SHORT
3	TDR100790	CV JOINT	
4	TDR100780	GAITER KIT OUTER	
5	FTC4822	SEAL	
6	CDU1534L	STAKE NUT	
7	FC112177P	BOLT	

REAR

8	TOD100020	DRIVESHAFT RH
8	TOD100030	DRIVESHAFT LH
9	TAY100050	HUB ASSEMBLY
10	FTC4919	O-RING
11	FC112127PL	BOLT
6	CDU1534L	STAKE NUT


Differential



1	FTC5142	DIFFERENTIALFRONT	4 BOLT
1	FTC5143	DIFFERENTIALREAR	3 BOLT
2	FRC4112	HOUSING	
3	BH112101L	BOLT	
4	FTC4210	DIFF LOCK RING	
5	576159	ROLL PIN	
6	539745	PINION BEARING SPACER	
7	539707	TAPER - ROLLER BEARING	
8	STC3722	FLANGE & MUDSHIELDFRONT	4 BOLT
8	STC3723	FLANGE & MUDSHIELDREAR	3 BOLT

9	FTC5258	SEAL	
10	FTC5322	FLANGE	FRONT 4 BOLT
10	FTC5323	FLANGE	REAR 3 BOLT
11	FTC5317	MUDSHIELD	
12	NY116041L	NUT	
13	PS608101L	SPLIT PIN	FRONT 4 BOLT
14	FS112301P	BOLT	
15	FTC5413	WASHER	
16	TYG100610	BOLT	
17	MULTIPLE	SHIM	



Door Locks & Latches



1	CXB103000H	EXTERIOR HANDLE	FRONT	RH
1	CXB103010	EXTERIOR HANDLE	FRONT	LH
1	CXB102910	EXTERIOR HANDLE	REAR	
2	CXF100310	PLATE		
3	FQJ102880	LATCH ASSEMBLY	FRONT	RH
3	FQJ102890	LATCH ASSEMBLY	FRONT	LH
4	FQM100700	LATCH ASSEMBLY	REAR	RH
4	FQM100710	LATCH ASSEMBLY	REAR	LH
5	FVC102200	HANDLE		RH

5	FVC102210	HANDLE		LH
6	CXB102190	HANDLE - TAILGATE		
7	FQR100570	LATCH - TAILGATE		
8	FQB100100	STRIKER - TAILGATE		
9	FRN100000	SEAL - STRIKER		
10	CKT700020	DOVETAIL - MALE	TO 1A 712430	
10	CKT700030	DOVETAIL - MALE	FROM 1A 712431	
11	ASR1515	DOVETAIL - FEMALE		
12	ALR8180	HANDLE - TAILGATE	INTERIOR	

Door Mirrors & Mudflaps




MANUAL MIRRORS

1	CRB109300	MIRROR	RH
1	CRB109310	MIRROR	LH
2	STC4625	ADAPTOR	
3	CRD100640	MIRROR GLASS	RH
3	CRD100650	MIRROR GLASS	LH
4	CSZ100120	RETAINING CLIP	

ELECTRIC MIRRORS


1	CRB110660	MIRROR	RH
1	CRB110670	MIRROR	LH
2	STC4625	ADAPTOR	
3	CRD100640	MIRROR GLASS	RH
3	CRD100650	MIRROR GLASS	LH



MUDFLAPS


1	CAS100900	MUDFLAP	RH	8	MXC6068	PLATE	(2)
1	CAS100910	MUDFLAP	LH	9	CAX100200	BRACKET-REAR	RH
2	CAX100060	BRACKET-FRONT	RH	9	CAX100210	BRACKET-REAR	LH
2	CAX100070	BRACKET-FRONT	LH	10	CNG100020	STAY-REAR	RH
3	MXC6094	BRACKET-FRONT	(2)	10	CNG100030	STAY-REAR	LH
4	SH106121L	SCREW	(3)	11	CYQ100140	POP RIVET	(2)
5	WA106041L	WASHER	(3)	12	FN106047L	NUT	(3)
6	WL106001L	WASHER	(3)	13	CAE100140	CLIP	(1)
7	NH106047L	NUT	(3)	14	CAE100160	CLIP	RH
				14	CAE100170	CLIP	LH

Body - Front



1	BKA700040	BONNET ASSEMBLY			
1a	BKB700020	BONNET HINGE RH			
1a	BKB700030	BONNET HINGE LH			
2	ASB700020	FRONT WING RH			
2	ASB700030	FRONT WING LH			
3	ALR9531	BULKHEAD			
4	ASR1047	SLAM PANEL			
5	ALR9518	HEADLAMP PANEL RH			
5	ALR9519	HEADLAMP PANEL LH			
6	ABJ700012	CROSSBRACE			
7	ABC700020	CROSS MEMBER			
8	CLF102040	WING LINER RH			
8	CLF102050	WING LINER LH			
9	ALR8810	BRACKET			
10	ASU700040	BAFFLE RH			
10	ASU700050	BAFFLE LH			
11	AWR3633PCM	GRILLE			
12	DHH100700PCM	HEADLAMP FINISHER RH			
12	DHH100710PCM	HEADLAMP FINISHER LH			
13	FVH100110	BADGE - LAND ROVER			
14	DPB104630	FRONT BUMPER	LESS FOG LAMPS	BLACK	
14	DPB104620	FRONT BUMPER	WITH FOG LAMPS	BLACK	
14	DPB104620LML	FRONT BUMPER	WITH FOG LAMPS	PRIMER	
15	ABU700041	BRACKET RH			
15	ABU700031	BRACKET LH			
16	DXC100210	STONEGUARD			
17	AWR4714	FOG LAMP BLANK RH	LESS FOG LAMPS	BLACK	
17	AWR4715	FOG LAMP BLANK LH	LESS FOG LAMPS	BLACK	
18	AWR4716	FOG LAMP BEZEL RH	WITH FOG LAMPS	BLACK	
18	AWR4717	FOG LAMP BEZEL LH	WITH FOG LAMPS	BLACK	
18	AWR4716LML	FOG LAMP BEZEL RH	WITH FOG LAMPS	PRIMER	
18	AWR4717LML	FOG LAMP BEZEL LH	WITH FOG LAMPS	PRIMER	
19	STC4351	TOW EYE COVER			

Doors



FRONT & REAR

22	BDB700060	HINGE	RH
22	BDB700070	HINGE	LH
23	BDH700030	CHECK STRAP	
24	ASR2098	BRACKET	

REAR


8	BFA700060	DOOR ASSEMBLY	RH
8	BFA700070	DOOR ASSEMBLY	LH
9	BFA700100	DOOR SKIN	RH
9	BFA700110	DOOR SKIN	LH
10	CGE101550	WAIST SEAL	RH
10	CGE101530	WAIST SEAL	LH
11	ELT100240	WAIST SEAL	RH
11	ELT100250	WAIST SEAL	LH
12	ASR1681	LOCATING CHANNEL	
13	391127	GLAZING STRIP	
14	MTC9274	LOCATING CHANNEL	RH
14	MTC9273	LOCATING CHANNEL	LH
15	CVB101920	DOOR GLASS	RH OPTIKOOL
15	CVB101930	DOOR GLASS	LH OPTIKOOL
15	CVB102620	DOOR GLASS	RH SUNDYM
15	CVB102630	DOOR GLASS	LH SUNDYM
15	CVB000370	DOOR GLASS	RH BLACK
15	CVB000360	DOOR GLASS	LH BLACK
16	CVB102660	DOOR GLASS	RH OPTIKOOL
16	CVB102670	DOOR GLASS	LH OPTIKOOL
16	CVB102640	DOOR GLASS	RH SUNDYM
16	CVB102650	DOOR GLASS	LH SUNDYM
16	CVB000390	DOOR GLASS	RH BLACK
16	CVB000380	DOOR GLASS	LH BLACK
17	MTC9177	CHANNEL	
18	ASR2096	CHANNEL	
19	CGE101510	SEAL	
20	ELD100960	WATER SHEDDER	RH
20	ELD100970	WATER SHEDDER	LH
21	CGE101940	SEAL	RH
21	CGE101950	SEAL	LH

FRONT

1	BDA100780	DOOR ASSEMBLY	RH
1	BDA100790	DOOR ASSEMBLY	LH
2	BDA700100	DOOR SKIN	RH
2	BDA700110	DOOR SKIN	LH
3	CGE101720	WAIST SEAL	RH
3	CGE101730	WAIST SEAL	LH
4	EJT100420	INNER WAIST SEAL	RH
4	EJT100430	INNER WAIST SEAL	LH
5	CUB102700	DOOR GLASS	RH
5	CUB102710	DOOR GLASS	LH
6	CFE103200	GLASS CHANNEL	
7	EJD101760	WATER SHEDDER	RH
7	EJD101770	WATER SHEDDER	LH


Manufacturers' part numbers are used for reference purposes only

Body Rear




- | | | |
|----|-----------|-------------------|
| 1 | ASR1084 | REAR QTR PANEL RH |
| 1 | ASR1085 | REAR QTR PANEL LH |
| 2 | ASR2220 | REAR INNER QTR RH |
| 2 | ASR2221 | REAR INNER QTR LH |
| 3 | DVK100030 | SEAL |
| 4 | BHD700080 | TAILDOOR ASSEMBLY |
| 5 | EOT100030 | WATER SHEDDER |
| 6 | CKE101000 | SEAL |
| 7 | ALR9290 | CHECKER |
| 8 | BHK700020 | SEAL |
| 9 | BHB700040 | LOWER HINGE |
| 9 | BHB700030 | UPPER HINGE |
| 10 | MXC8775 | GASKET - LOWER |
| 10 | MXC8774 | GASKET - UPPER |
| 11 | DQB102180 | REAR BUMPER |
| 12 | DQR101080 | FINISHER RH |
| 12 | DQR101090 | FINISHER LH |
| 13 | DPP100970 | TREAD PLATE |

Window Regulators



- | | | |
|---|-----------|--------------------|
| 1 | CUH102300 | FRONT REGULATOR RH |
| 1 | CUH102310 | FRONT REGULATOR LH |
| 2 | CUR100440 | FRONT MOTOR RH |
| 2 | CUR100450 | FRONT MOTOR LH |
| 3 | CVH101240 | REAR REGULATOR RH |
| 3 | CVH101250 | REAR REGULATOR LH |
| 4 | CUR100440 | REAR MOTOR RH |
| 4 | CUR100450 | REAR MOTOR LH |

Body Finishers




1	DDG100381	D-POST FINISHER	RH
1	DDG100391	D-POST FINISHER	LH
2	MXC8807	NUT	
3	DDE101720	FINISHER REAR TONNEAU	RH
3	DDE101730	FINISHER REAR TONNEAU	LH
4	DYP101510	SCREW	
5	DYH100950	NUT	
6	DDJ100600	SILL FINISHER (A) (1)	RH
6	DDJ100610	SILL FINISHER (A) (1)	LH
6	DDJ100820	SILL FINISHER (A) (2)	RH
6	DDJ100830	SILL FINISHER (A) (2)	LH
6	DDJ100840	SILL FINISHER (B)	RH
6	DDJ100850	SILL FINISHER (B)	LH
7	ESR1560	NUT	
8	ANR2224	RIVET - PLASTIC	
9	DFJ100440	FRONT WHEELARCH FLARE	RH
9	DFJ100450	FRONT WHEELARCH FLARE	LH
10	DFK100860	REAR WHEELARCH FLARE	RH
10	DFK100870	REAR WHEELARCH FLARE	LH
11	DFK100940	REAR WHEELARCH FLARE	RH
11	DFK100950	REAR WHEELARCH FLARE	LH
12	DCB000280PMA	A-POST FINISHER	RH
12	DCB000290PMA	A-POST FINISHER	LH
13	79086L	RIVET - PLASTIC	
14	DFK100900	REAR WHEELARCH FLARE	RH
14	DFK100910	REAR WHEELARCH FLARE	LH
15	DDZ100000	FILLER	RH
15	DDZ100010	FILLER	LH
16	DDZ100020	FILLER	
17	DYH101090	FINISHER	

KEY

- A REAR MUDFLAPS
- B FRONT & REAR MUDFLAPS
- 1 TO YA 266555
- 2 FROM YA 266556

Front & Rear Brakes




FRONT

1	SDB000380	BRAKE DISC
2	SFP100480	BRAKE PADS
3	FTC4908	SHIELD RH
3	FTC4909	SHIELD LH
4	SF108201L	SCREW
5	FS106127PL	BOLT
6	STC1916	CALIPER RH
6	STC1915	CALIPER LH
7	STC1919	CALIPER REPAIR KIT
8	STC1918	PISTON
9	STC1920	GUIDE PIN KIT
10	STC1911	DUST COVER
11	STC1917	CALIPER CARRIER

REAR

1	SDB000470	BRAKE DISC
2	SFP100490	BRAKE PADS
3	FTC4778	SHIELD
4	SF108201L	SCREW
5	FS106127PL	BOLT
6	STC1906	CALIPER RH
6	STC1905	CALIPER LH
7	STC1909	CALIPER REPAIR KIT
8	STC1908	PISTON
9	STC1910	GUIDE PIN KIT
10	STC1911	DUST COVER
11	STC1907	CALIPER CARRIER

Braking Systems




LH DRIVE	
SJG100250	SERVO ASSEMBLY
SJC100432	MASTER CYLINDER

1	SJC100442	MASTER CYLINDER	
2	SJJ100362	MASTER CYLINDER REPAIR KIT	
3	SJG000040	SERVO	
4	SJO100080	SEAL - BRAKE SERVO	
5	ICW100030	HANDBRAKE SHOES	
6	NTC9859	HANDBRAKE DRUM - TD5	
6	FRC3502	HANDBRAKE DRUM - V8	
7	SF108201L	SCREW	
8	ICW100050	SHOE RETENTION KIT	
9	STC1536	CROSS SHAFT	
10	SID100040	FILTER - RESEVIOR	
11	ICW100040	BRAKE ADJUSTER KIT	
12	SMF100220	BACKPLATE	
13	ICW100000	SHOE RETENTION KIT	
14	ICW100010	LEVER KIT	
15	SPB101500	HANDBRAKE CABLE	TO XA 224663
15	SPB101540	HANDBRAKE CABLE	XA 224664 - 1A 734207
15	SPB000150	HANDBRAKE CABLE	FROM 1A 734208

Manufacturers' part numbers are used for reference purposes only


Clutch




1	FTC4630	CLUTCH COVER	TD5
1	FTC5301	CLUTCH COVER	V8
2	FTC4631	CLUTCH PLATE	TD5
2	FTC4789	CLUTCH PLATE	V8
3	FTC5200	RELEASE BEARING	
4	FTC5202	SLAVE CYLINDER	
5	FTC5199	PUSH ROD	
6	576723	CLIP	
7	576137	RELEASE ARM	
8	576203	STAPLE	

9	571161	INSERT	
10	FRC2975	CAP	
11	571163	CLIP	
12	FS106101L	BOLT	
13	FTC4720	GUIDE - RELEASE BEARING	
14	FB108091L	BOLT	
15	FRC2481	DOWEL	
16	STC100400	MASTER CYLINDER	TD5
16	ANR6727	MASTER CYLINDER	V8 TO XA 232916
16	STC100390	MASTER CYLINDER	V8 FROM XA 232917

Wash/Wipe System




1	AMR5114	HOSE & JET - HEADLAMP WASH
2	DNE100050	VALVE - NON RETURN
3	DMC100560	PUMP - HEADLAMP WASH
4	DMC100550	PUMP - WINDSCREEN WASH
5	DMC100540	PUMP - REAR SCREEN WASH
6	AWR2406	JET - REAR SCREEN WASH
7	DNJ100730	JET - WINDSCREEN WASH
8	DNH101570	WINDSCREEN WASH ASSEMBLY
9	DMB102980	CONTAINER - NO HEADLAMP WASH
9	DMB102970	CONTAINER - WITH HEADLAMP WASH



1	DKD100620	MECHANISM & MOTOR - FRONT WIPER
2	DKB102830	FRONT WIPER ARM
3	DKC100960	FRONT WIPER BLADE
4	DLP000010	NUT - FRONT WIPER ARM
5	DKG100120	CAP - FRONT WIPER ARM
6	DKW100020	CLIP - BLADE TO ARM
7	DLB101640	REAR WIPER MOTOR
8	DKB102700	REAR WIPER ARM
9	DKC100890	REAR WIPER BLADE
10	AMR3932	GROMMET - REAR WIPER ARM
11	AMR3933	WASHER - REAR WIPER ARM
12	AMR3934	NUT - REAR WIPER ARM
13	FN108047L	NUT - REAR WIPER ARM
14	DKG100090	CAP - REAR WIPER SPINDLE
15	AMR3550	GROMMET


Interior Switches



1	YUF101521LNF	FRONT WINDOW LIFT
2	YUF000200LNF	REAR WINDOW LIFT
3	AMR2497	ISOLATOR - WINDOW LIFT
4	YUG102440	HEATED SEAT RH
5	YUG102430	HEATED SEAT LH
6	YUB101041	SEAT SWITCH PACK RH
6	YUB101051	SEAT SWITCH PACK LH
7	YUB101080	SEAT SWITCH PACK RH
7	YUB101060	SEAT SWITCH PACK LH
8	HSD100071	CAP - SEAT RECLINER RH
8	HSD100061	CAP - SEAT RECLINER LH
9	HSD100080	CAP - SEAT RECLINER
10	FIH100000LNF	ESCUTCHEON RH
10	FIH100010LNF	ESCUTCHEON LH
11	YUG102620	FRONT FOG
12	YUE100670	REAR FOG
13	YUE100590	REAR WASH/WIPE


14	YUE100600	REAR WIPER	
15	AMR5433	BLANK	
16	AMR5433	BLANK	
17	YUH100370	CRUISE CONTROL	
18	AMR5433	BLANK	
19	AMR2745	THUMBWHEEL - ILLUMINATION	
20	STC1877	BULB/HOLDER - ORANGE	
20	STC1878	BULB/HOLDER - GREEN	
21	YUG102382	HILL DECENT	
22	YUG102372	HAZARD LIGHTS	
23	YUG102550	HEATED WINDSCREEN	
24	YUF101751	OFF ROAD LEVEL	
25	YUG102390	FUEL FLAP RELEASE	
26	YUG102540	HEATED REAR WINDOW	
27	YUF101790	MASTER DOOR LOCK	TO 2A 759146
27	YUF000220LNF	MASTER DOOR LOCK	FROM 2A 756147
0	AMR5428	AIR CONDITIONING SWITCH	

Electrical (Lighting)



1	XBC105120	HEADAMP RH	7	STC3368	ADJUSTER
1	XBC105130	HEADLAMP LH	8	STC1239	BULB COVER
2	XBD100870	INDICATOR RH	9	STC1232	FIXINGS KIT
2	XBD100880	INDICATOR LH	10	AMR2706	MOTOR
3	XGB000030	SIDE REPEATER	11	STC8646	GROMMET
4	XFB000040	REAR LAMP RH	12	STC1240	BULB HOLDER
4	XFB000050	REAR LAMP LH	13	YPY100220	BULB HOLDER
5	XGB101480	REAR LAMP RH	14	XFM100320	BULB HOLDER RH
5	XGB101490	REAR LAMP LH	14	XFM100330	BULB HOLDER LH
6	STC1713	GASKET RH	15	XFM100310	BULB HOLDER
6	STC1714	GASKET LH	16	XFH100430	GASKET



Electrical (Engine)



TD5	ERR6999	ALTERNATOR	V8	ERR6413	ALTERNATOR
TD5	NAD101240	STARTER MOTOR	V8	NAD101240	STARTER MOTOR
TD5	ERR6066	GLOW PLUG	V8	ERR6045	IGNITION COIL
			V8	NLP100320	SPARK PLUG
			V8	BRA 2002	HT LEAD SET

LH DRIVE	
XBC105140	HEADLAMP RH LHD
XBC105150	HEADLAMP LH LHD

Exhaust Manifold & Turbo





TD5

1	LKC102020	MANIFOLD
2	LKG100470	GASKET
3	TE108051L	STUD
4	ESR2033	NUT
5	ERR6768	GASKET
6	PMF100460	TURBOCHARGER TO 1A 736339
6	PMF000040	TURBOCHARGER FROM 2A 736340
7	PNT100030	GASKET
8	PMK100130	WASTEGATE

V8

A	ERR7394	MANIFOLD RH
A	ERR7393	MANIFOLD LH
B	ERR6733	GASKET
C	ERR6318	SPACER
D	ERR551L	STUD
E	ERR6734	BOLT

Exhaust System



TD5


1	WCD000960	DOWNPIPE
1	WCD000500	DOWNPIPE WITH CATALYST
2	WDE100590	CENTRE SILENCER
3	WDE100660	REAR SILENCER
4	ESR3737	GASKET
5	ESR3172	MOUNTING
6	NV110041L	NUT

V8

1	WCD105880	DOWNPIPE	TO 1A 708004
1	WCD000200	DOWNPIPE	FROM 1A 708005
2	WCE104640	CENTRE SILENCER	
3	WDE100650	REAR SILENCER	
4	ESR3737	GASKET	
5	ESR3172	MOUNTING	
6	NV110041L	NUT	
7	MHK100920	LAMBDA SENSOR	




Manufacturers' part numbers are used for reference purposes only

Fuel System



1	ESR4672	FUEL TANK	TD5	
1	ESR4676	FUEL TANK	V8	TO 2A 736339
1	WHK000090	FUEL TANK	V8	FROM 2A 736340
2	WFI100090	CRADLE		
3	WFX101080	PUMP	TD5	
3	WFX000130	PUMP	V8	
4	ESR3807	ADAPTOR		
5	ESR3806	SEAL		
6	ESR3808	LOCKING RING		

Service Parts / Belts / Gaskets



TD5

OIL FILTER	LPX100590
ROTOR FILTER	ERR6299
FUEL FILTER	ESR4686
AIR FILTER	ESR4238
ROCKER GASKET	ERR7094
OIL FILLER CAP SEAL	LUD100040L
SUMP GASKET	LVF100380
SUMP WASHER	CDU1001L
GLOW PLUG	ERR6066



4.0 V8

OIL FILTER	ERR3340
AIR FILTER	ESR4238
FUEL FILTER	ESR4065
CRANK VENT	ERR4563
ROCKER GASKET	ERR7288
SUMP GASKET	LVF100400
SUMP WASHER	ALU1403L
SPARK PLUG	NLP100320L

ENGINE NOTE	YEAR	FAN BELT	TIMING BELT	COVER GASKET	W/PUMP GASKET
4.0 V8	99 on	ERR6899	ERC7929	ERR7280	ERR4077
4.0 V8 A/CON	99 on	ERR6898	ERC7929	ERR7280	ERR4077
4.0 V8 ACE	99 on	ERR6897	ERC7929	ERR7280	ERR4077
4.0 V8 A/CON & ACE	99 on	ERR6896	ERC7929	ERR7280	ERR4077
TD5	99 on	PQS101500	LXB100090	sealant	PQF10001L
TD5 A/CON	99 on	PQS101490	LXB100090	sealant	PQF10001L
TD5 ACE	99 on	PQS101520	LXB100090	sealant	PQF10001L
TD5 A/CON & ACE	99 on	PQS101510	LXB100090	sealant	PQF10001L

Other Engine parts:
 Belts p6
 Miscellaneous Parts p25
 Timing p24
 Gaskets p32

Steering




1	QAF00010	STEERING BOX
2	QJF100140	DROP ARM
3	QGK100060	WASHER
4	QFG100090	NUT
5	QEP105390	PIPE
6	QGB100010	COVER
7	QFW100140	MAIN SEAL KIT
8	QFW100150	INPUT SEAL KIT
9	QFW100180	OUTPUT SEALKIT
10	QFW100190	SEAL REPAIR KIT

11	QHG000040	DRAG LINK ASSEMBLY
12	QEK000020	DRAG LINK TUBE
13	QFS000010	BALL JOINT - SHORT ARM
14	STC3107	CLAMP
15	STC3109	FLANGE NUT
16	STC3108	CLAMP
17	ANR1000	LOCK NUT
18	QHH100001	STEERING DAMPER
19	ANR3671	BUSH

LH DRIVE
QAF100150 STEERING BOX

Shock Absorbers & Springs



KEY
 * FROM 2A 737590
 CS COIL SPRUNG
 SL SELF LEVELLING SUSPENSION
 ACE ACTIVE CORNERING ENHANCEMENT

FRONT


1	REB101340	COIL SPRING	TD5	
1	REB101330	COIL SPRING	V8	
2	RNB103533	DAMPER	NO ACE	CS
2	RNB103683	DAMPER	ACE	CS
2	RNB103533	DAMPER	NO ACE	SL
2	RNB103694	DAMPER	ACE	SL
3	ROA100050	TOP BUSH		
4	ROA100040	BOTTOM BUSH		
5	KVU101051	BRACKET		
6	RBC100111	ISOLATOR		
7	REG000020	SEAT RH		
7	REG000030	SEAT LH		
8	RNV100060	BUMP STOP		

REAR

9	RKB101101	COIL SPRING RH		CS
9	RKB101100	COIL SPRING LH		CS
9	RKB000340	COIL SPRING RH	*	SL
9	RKB000350	COIL SPRING LH	*	SL
10	RKB101200	AIR SPRING		SL
11	RPD102333	DAMPER	NO ACE	CS
11	RPD102343	DAMPER	ACE	CS
11	RPD102363	DAMPER	NO ACE	SL
11	RPD102354	DAMPER	ACE	SL
12	ROA100050	BUSH		
13	ANR3482	BOLT		
14	ANR2938	ISOLATOR		CS
15	ANR3578	SEAT		CS
16	RQH100030	HEIGHT SENSOR		
17	RNV100060	BUMP STOP		

Manufacturers' part numbers are used for reference purposes only


Front Suspension



1	RBI100040	PANHARD ROD
2	ANR3671	BUSH
3	RDI100020	BOLT
4	ANR4386	BOLT
5	ANR3140	NUT
6	RBL101370	ANTI ROLL BAR
7	RBM100223	ANTI ROLL BAR LINK
8	RYH100590	NUT
9	RBX101690	BUSH

10	RBU100240	BRACKET	
11	RBJ102353	RADIUS ARM	
12	RBX101680	BUSH	
13	ANR3140	NUT	
14	RBX101730	BUSH	
15	ANR6920	BOLT	TO XA 905159
15	RDI100031	BOLT	FROM XA 905160
16	ANR5804	BOLT	

Rear Suspension



1	RGG104862	RADIUS ARM	
2	RBX101730	BUSH	
3	ANR6947	BUSH	
4	ANR3140	NUT	
5	ANR5804	BOLT	
6	ANR6920	BOLT	
7	RGD100550	WATTS LINKAGE	
8	RGD100450	ARM & BUSH	
9	RGX100970	LINK BUSH	
10	RGW100020	ROLLER BEARING	
11	RGX100960	BUSH	
12	RHD100080	BOLT	
13	FX214057	NUT	
14	ANR6920	BOLT	
15	ANR3140	NUT	
16	RHD100080	BOLTS	
17	FX214057	NUT	
18	RGB101320	ANTI ROLL BAR	COIL SPRUNG
18	RGB101310	ANTI ROLL BAR	AIR SUSPENSION
18	RGB000180	ANTI ROLL BAR	FROM 2A 736340
19	RGD100682	ANTI ROLL BAR LINK	
20	RYH100590	NUT	
21	RBX101710	BUSH	COIL SPRUNG
21	RBX101700	BUSH	AIR SUSPENSION
22	RBU100240	BRACKET	

LH DRIVE		
1	RBI1000500	PANHARD ROD